


### Spotlights




Turn on the spotlight by pushing the button next to each light. Push the button again to turn it off. You can use the spotlights at all times.

*On EX and SE models*


The ceiling light (with the switch in the center position) also comes on when you unlock the door with the remote transmitter (see page 72 ).

### Cargo Area Light



The cargo area light has a three-position switch. In the OFF position, the light does not come on. In the center position, the light comes on when you open the tailgate. In the ON position, the light stays on continuously.

### Ignition Switch Light



The ignition switch light comes on when you open the driver's door, and stays on several seconds after you close the door.