



VERTICAL ANGLE GAUGE




6. Check the vertical angle gauge. The bubble should be centered underneath the longest scribe mark on the gauge.

HORIZONTAL ADJUSTMENT



7. If either indicator is not aligned with its "0" mark as described, an adjustment can be made using a Phillips-head screwdriver to realign it with the "0" mark. Please refer to the illustrations.

VERTICAL ADJUSTMENT



8. If you cannot get an indicator to align, have your Honda dealer inspect the vehicle for body damage or suspension problems.