

This section explains why it is important to keep your vehicle well maintained and to follow basic maintenance safety precautions.

This section also includes Maintenance Schedules for normal driving and severe driving conditions, a Maintenance Record, and instructions for simple maintenance tasks you may want to take care of yourself.

If you have the skills and tools to perform more complex maintenance tasks on your Honda, you may want to purchase the Service Manual. See page 309 for information on how to obtain a copy, or see your Honda dealer.

Maintenance Safety.....	198
Important Safety Precautions ..	199
Maintenance Schedule.....	200

Required Maintenance Record....	207
Owner Maintenance Checks.....	209
Fluid Locations.....	210
Engine Oil.....	211
Adding Oil.....	211
Recommended Oil.....	211
Synthetic Oil.....	212
Additives.....	212
Changing the Oil and Filter.....	213
Cooling System.....	215
Adding Engine Coolant.....	215
Replacing Engine Coolant	217
Windshield Washers.....	220
Transmission Fluid.....	221
Automatic Transmission.....	221
5-speed Manual	
Transmission.....	222
Rear Differential Fluid.....	223
Brake and Clutch Fluid.....	224
Brake System.....	224
Clutch System.....	225
Power Steering.....	225
Air Cleaner Element.....	226
Hood Latch.....	227
Spark Plugs.....	227
Replacement.....	227

Specifications.....	228
Battery.....	229
Wiper Blades.....	231
Air Conditioning System.....	233
Air Conditioning Filter.....	234
Drive Belts.....	234
Timing Belt.....	235
Tires.....	235
Inflation.....	235
Recommended Tire	
Pressures for Normal	
Driving.....	236
Inspection.....	237
Maintenance.....	237
Tire Rotation.....	238
Replacing Tires and Wheels	239
Wheels and Tires.....	240
Winter Driving.....	240
Snow Tires.....	240
Tire Chains.....	241
Lights.....	242
Headlight Aiming	244
Replacing Bulbs	246
Storing Your Vehicle.....	253