

Comfort and Convenience Features

Heating and Cooling.....	128	Adjusting the Sound.....	159
What Each Control Does.....	128	Audio System Lighting	160
How to Use the System.....	131	Radio Frequencies.....	160
To Turn Everything Off	136	Radio Reception	161
Audio System	137	Digital Clock.....	162
Audio System (U.S. and		Operating the Cassette	
Canadian LX)	138	Player	164
AM/FM/Cassette/CD Audio		Tape Search Functions	165
System.....	138	Caring for the Cassette	
Operating the Radio	139	Player	168
Adjusting the Sound	143	Operating the CD Changer	169
Audio System Lighting	144	Loading CDs in the Changer ...	170
Digital Clock.....	144	Operation.....	172
Operating the CD Player	146	Removing CDs from the	
CD Player Error Indications.....	148	Changer	174
Operating the CD Changer	149	Protecting Compact Discs.....	176
CD Changer Error		CD Changer Error	
Indications	150	Indications	177
Operating the Cassette		Theft Protection	178
Player	151	Cruise Control.....	179
Tape Search Functions	152		
Audio System (U.S. EX and			
Canadian EX and EX-L)	154		
AM/FM/Cassette/CD			
Changer Audio System.....	154		
Operating the Radio	155		