

This section gives you tips on starting the engine under various conditions, and how to operate the 5-speed manual and automatic transmissions. It also includes important information on parking your vehicle, the braking system, and facts you need if you are planning to tow a trailer or drive off-highway.

Driving Guidelines.....	198
Preparing to Drive	199
Starting the Engine.....	200
Starting in Cold Weather	
at High Altitude	201
5-speed Manual Transmission	202
Recommended Shift Points.....	203
Engine Speed Limiter	203
Automatic Transmission.....	204
Shift Lever Position Indicator ..	204
Shift Lever Positions	205
Engine Speed Limiter	208
Shift Lock Release.....	209
Parking.....	210
The Braking System.....	211
Brake Wear Indicators.....	211
Brake System Design.....	212
Anti-lock Brakes	212
Important Safety	
Reminders	213
ABS Indicator	214
Driving in Bad Weather	215
Towing a Trailer	217
Towing Your Vehicle Behind a	
Motorhome.....	224

Off-Highway Guidelines	226
General Information.....	226
Important Safety Precautions ..	227
Driving Tips.....	228