

This section explains why it is important to keep your vehicle well maintained and to follow basic maintenance safety precautions.

This section also includes Maintenance Schedules for normal driving and severe driving conditions, a Maintenance Record, and instructions for simple maintenance tasks you may want to take care of yourself.

If you have the skills and tools to perform more complex maintenance tasks on your Honda, you may want to purchase the Service Manual. See page 357 for information on how to obtain a copy, or see your Honda dealer.

Maintenance Safety	234
Important Safety Precautions ..	235
Maintenance Schedule	236

Required Maintenance Record	243
Owner Maintenance Checks.....	245
Fluid Locations.....	246
Engine Oil.....	247
Adding Oil.....	247
Recommended Oil.....	247
Synthetic Oil.....	248
Additives	248
Changing the Oil and Filter.....	249
Cooling System	251
Adding Engine Coolant.....	251
Replacing Engine Coolant	253
Windshield Washers	258
Transmission Fluid.....	260
Automatic Transmission.....	260
5-speed Manual	
Transmission.....	261
Rear Differential Fluid.....	262
Brake and Clutch Fluid.....	263
Brake System	263
Clutch System	264
Power Steering.....	264
Air Cleaner Element.....	265
Hood Latch	266
Spark Plugs.....	267
Replacement.....	267

Specifications	268
Battery	269
Wiper Blades	271
Air Conditioning System.....	274
Dust and Pollen Filter	275
Drive Belt.....	277
Tires	278
Inflation.....	278
Recommended Tire	
Pressures for Normal	
Driving	279
Tire Pressure Adjustment for	
High Speed Driving	279
Inspection	280
Maintenance	280
Tire Rotation	281
Replacing Tires and Wheels	282
Wheels and Tires.....	283
Winter Driving	283
Snow Tires.....	283
Tire Chains	284
Lights	285
Headlight Aiming	287
Replacing Bulbs	287
Storing Your Vehicle	295