

You should do the following checks and adjustments every day before you drive your vehicle.

- | | | |
|---|---|---|
| 1. Make sure all windows, mirrors, and outside lights are clean and unobstructed. Remove frost, snow, or ice. | 5. Check the adjustment of the seat (see page 97). | 10. Turn the ignition switch ON (II). Check the indicator lights in the instrument panel. |
| 2. Check that the hood, tailgate and hatch glass are fully closed. | 6. Check the adjustment of the inside and outside mirrors (see page 114). | 11. Start the engine (see page 200). |
| 3. Visually check the tires. If a tire looks low, use a gauge to check its pressure. | 7. Check the adjustment of the steering wheel (see page 83). | 12. Check the gauges and indicator lights in the instrument panel (see page 65). |
| 4. Check that any items you may be carrying with you inside are stored properly or fastened down securely. | 8. Make sure the doors are securely closed and locked. | |
| | 9. Fasten your seat belt. Check that your passengers have fastened their seat belts (see page 17). | |